
Door Locks

$\, n \,$ Locking the vehicle from inside



- ▶ Inside lock button
- 1 Locks
- 2 Unlocks



- ► Door lock switches
 Operates all door locks/unlocks.
- 1 Locks
- 2 Unlocks

n Locking the vehicle from outside

Using the entry function or wireless remote control (\rightarrow P.12, 13)

$n \ \ \mathsf{Rear} \ \mathsf{door} \ \mathsf{child}\text{-}\mathsf{protector} \ \mathsf{lock}$



Pushing down the switch prevents the rear doors from being opened from the inside.

Always set the child protector locks when children are seated in the rear seat.

Power Windows



1 Power window switches

To open: press the switch.

To close: pull the switch up.


Fully pulling up and releasing the switches causes the windows to close fully. Fully pressing down and releasing the switches causes the windows to open fully.

2 Window lock switch

The window lock switch disables the operation of passenger and rear window switches.

Moon Roof (If Equipped)

n Opening and closing



1 Opens

The moon roof stops slightly before the fully opened position.

To fully open, press the switch again.

2 Closes

To stop partway, press the switch lightly.

n Tilt up and down



1 Tilts up

2 Tilts down

To stop partway, press the switch lightly.

Fuel Tank Cap



1 Press the fuel filler door opener.



2 Slowly remove the cap by turning it counterclockwise.

After the cap is removed, it can be hung on the inside of the fuel filler door.

Back Door

n Back door opener button



To open the back door, push up the opener button and raise the door.

n Power back door switches (with power back door)



▶ Instrument panel

To open or close the back door, press the switch.



▶ Wireless remote control (\rightarrow P.12)


▶ Back door

To close the back door, press the switch.

n Back door closer (with power back door)

If the back door is left slightly open, it will close automatically.

n Turning the power back door system on and off (with power back door)



To disable the system, turn off the main switch in the glove box.

- 1 On
- 2 Off

When the power back door system is disabled, the back door cannot be opened using the wireless remote control or power back door switch.